

REPAIR KITS & PARTS

■ FLAT BOX MAINTENANCE KIT - FBK01

Covers commonly required parts for general maintenance. Use this kit when the box is leaking due to wear between the pressure plate axle and the nyliners.

Contents:
 F025 Pressure Plate Axle x 1
 F008 Nyliner x 2
 F009 Blade x 1
 SA051 Thumb Screw x 2
 AT062 4-40 x 5/16" BH Screw x 7,9

Code	Barcode
FBK01-200	9315778991315
FBK01-250	9315778991322
FBK01-300	9315778991339



Available in 150mm, 200mm, 250mm and 300mm.

■ FLAT BOX SERVICE KIT - FBK02

Replaces the seals, skids and wheels. Use this kit when the box is leaking due to the seals being worn or deteriorated. Also includes other harder wearing components such as skids and wheels.

Contents:
 F030 Pressure Plate Wiper x 1
 F017 Axle Wiper x 1
 F006 Skid x 1
 F024 Skid x 1
 FA020 Tyre & Wheel x 2
 F032 Bushing x 2
 F007 5-40 x 1/8" BH Screw x 4

Code	Barcode
FBK02-200	9315778991346
FBK02-250	9315778991353
FBK02-300	9315778991360



Available in 150mm, 200mm, 250mm and 300mm.

■ FLAT BOX OVERHAUL KIT - FBK03

Includes all wear items to fully overhaul the flat box. Use this kit when the box has been used for an extended period and all wear items require replacement.

Contents:
 FBK01 Maintenance Kit x 1
 FBK02 Service Kit x 1
 F039 Blade Holder x 1
 F044 Blade Holder Tab x 4
 F034 Spring x 1
 F028 10-32 Wing Nut X 2
 F042 Pressure Plate Spring x 2
 AT042 4-40 x 5/16" Screw x 2

Code	Barcode
FBK03-200	9315778991377
FBK03-250	9315778991384
FBK03-300	9315778991391



Available in 200mm, 250mm and 300mm.

■ FLAT BOX HANDLE MAINTENANCE KIT - FHK01

Replaces the major wear components - hinge assembly, locking cam and retainer. Use this kit when the brake action is ineffective due to wear in these components, and the hinge is bottoming out.

Contents:
 FHA002 Hinge Assembly x 1
 FH005N Locking Cam x 1
 FH007 Retainer x 1

Code	Barcode
FHK01	9315778995894

■ CORNER ROLLER MAINTENANCE KIT - CRK01

Replaces the rollers and bushes. Use this kit when the corner rollers are too loose and the roller ends may be catching on the wall.

Contents:
 CR002 Bushings x 4
 CR003 Roller S/S x 4
 CR004 1/4" -20 x 1-1/4" Hex Hd x 4

Code	Barcode
CRK01	9315778995863

■ AUTO TAPER MAINTENANCE KIT - ATK01

Replaces the rollers and bushes. Use this kit when the corner rollers are too loose and the roller ends may be catching on the wall.

Contents:
 AT218 Creaser Cable x 1
 AT248 Puller Cable x 1
 AT243-1 Cup Wiper Modified x 1
 ATK141 O Ring (BS225) x 1
 B051 Bearing Liner x 1
 AT031 Pyramid Cutter Blade x 1
 AT074 Needle x 1
 AT005 Creaser Return Spring x 1

Code	Barcode
ATK01	9315778002950

■ CORNER BOX MAINTENANCE KIT - CBK01

Replaces the pressure plate axle and nyliners. Use this kit when the box is leaking due to wear between these components.

Contents:
 F008 Nyliner x 2
 CB014 Axle x 1
 AT062 4-40 x 5/16" BH Screw x 3

Code	Barcode
CBK01	9315778998185

■ CORNER BOX SERVICE KIT - CBK02

Replaces the seals. Use this kit when the box is leaking due to the seals being worn or deteriorated.

Contents:
 S012-75 Axle Wiper 75mm x 1
 CB020 Pressure Plate Wiper x 1

Code	Barcode
CBK02	9315778995436

■ CORNER FINISHER MAINTENANCE KIT - CFK01

Covers resetting the Corner Finisher, replacing skids and grub screws. Use this kit when the finisher is leaving thick edges or ripping tape.

Contents:
 CF002 6-32 x 1/8" Set Screw x 10
 CF013 Skid x 2

Code	Barcode
CFK01	9315778991445

■ CORNER FINISHER SERVICE KIT - CFK02

Replaces blades, clips, ball retainer and associated screws. Use this kit when the blades are broken or damaged and clips are worn. To check blades, run a fingernail along the leading edge. You should be able to feel a crack or break.

Contents:
 CF10/22 Size Carbide Blade x 2
 AT012 8-32 x 1/4" Set Screw x 2
 CFA116 Lower Clip Assembly x 1
 CF103 Upper Clip x 1
 CF020 Ball Retainer x 1

Code	Barcode
CFK02-65	9315778996136
CFK02-75	9315778996419
CFK02-90	9315778995412



Available in 65mm, 75mm & 90mm

■ LOADING PUMP MAINTENANCE KIT - LPK01

Replaces the rubber components. Use this kit when the pump is not sealing properly and performance is low.

Contents:
 P003 Piston Wiper x 1
 P004 O Ring Piston x 1
 P036 O Ring x 1
 P031 U Cup x 1
 P051 O Ring x 1

Code	Barcode
LPK01	9315778995870

■ LOADING PUMP SERVICE KIT - LPK02

Replaces the piston rod bush and suction screen. Use this kit when these components are worn or damaged.

Contents:
 P030 Nylon Bushing x 1
 P025F Screen Fine x 1

Code	Barcode
LPK02	9315778995887

■ NAIL SPOTTER MAINTENANCE KIT - NSK01

Replaces common wear parts including the blade which can be damaged.

Contents:
 S005** Blade x 1
 S006** Pressure Plate Wiper x 1
 S012** Axle Wiper x 1
 S014 Wheel x 2
 S015 Tyre x 2
 S017 Nyliner x 2
 S039 Nyliner x 2

Code	Barcode
NSK001-55	9315778016209
NSK01-75	9315778016216



Available in 55mm & 75mm